

DH300 Curve Digital Hub Quick Reference Guide





en-US

APRIL 2024

©2024 Motorola Solutions, Inc. All rights reserved



MN009237A01-AA

DH300 Curve Digital Hub Quick Reference Guide

This Quick Reference Guide covers the basic operation of the device. For more operational details and information, see MN009243A01 DH300, CB400 Series Installation Guide at https:// www.motorolasolutions.com/curve-resources.

Important Safety Information

ATTENTION!

Before using this product, read the RF Energy Awareness and Acoustic Safety information and operating instructions.

RF Energy Exposure Awareness and Control Information and Operational Instructions for Occupational Use



NOTE: This device is intended for use in occupational/controlled conditions where users are aware of their exposure and can exercise control over their exposure to meet the requirements in national and international regulations. This device is not authorized for general population, consumer use.

Observe a minimum safe distance of 80 cm from the device to the operator.

For more information on what RF energy exposure is, and how to control your exposure to ensure compliance with established RF exposure limits. consult the following websites:

- https://www.fcc.gov/
- https://www.osha.gov/
- https://osha.europa.eu/en
- https://www.arpansa.gov.au/
- https://www.who.int/health-topics/electromagnetic-fields/ http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf11467.html
- http://www.ic.ac.ca/eic/site/smt-ast.nsf/eng/sf01904.html

For additional user training information on exposure requirements, consult the following websites:

https://www.motorolasolutions.com/en_us/about/company-overview/ corporate-responsibility/governance-and-policies.html

http://learning.motorolasolutions.com/

DH300 Curve Digital Hub Overview




Table 1: DH300 Curve Digital Hub Overview

No	Description
1	LED Indicator
2	3.5 mm Audio Jack
3	USB-2 Service Connector
4	RJ45 Ethernet Connector
5	12 VDC Power Input Connector

Getting Started

Connecting through Ethernet Port

- 1. Connect to the DC power adaptor.
- Connect the DH300 to your local LAN using the Ethernet connector. The DH300 IP address is Dynamic Host Configuration Protocol (DHCP) and automatically connects to the internet and starts provisioning in within 45 seconds.

The Transmission Control Protocol (TCP)/Internet protocol (IP) ports must be open. The default settings are TCP port 443 and UDP ports 53 and 123.

LED Indicators

Table 2: LED Indicators

LED Indicators	Status	Troubleshooting	
Solid Red	Hub is powering up.	-	
Solid Blue	Hub is provisioning the cloud deployment.	-	
Blinking White	Connection established.	-	
Blinking Green	Audio communication transmission is in progress.	-	
Solid Green	Transmitting audio communication.	-	
Solid Yellow	Internet is connected but the hub connection to the cloud server is not successful.	Check the internet connection.	
Blinking Yellow	No internet connection.	Check the internet connection.	
Blinking Red	Communication with the modem is not successful. Faulty hub.	Contact technical support.	

NOTES

NOTES



https://learning.motorolasolutions.com/installation-guide/80396 enus

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.

© 2024 Motorola Solutions, Inc. All rights reserved.



Printed in