


T62

OWNER'S MANUAL

en-US

zh-CN



RF ENERGY EXPOSURE AND PRODUCT SAFETY GUIDE FOR PORTABLE TWO-WAY RADIOS

ATTENTION!

Before using this product, read the RF Energy Exposure and Product Safety Guide that ships with the radio which contains instructions for safe usage and RF energy awareness and control for compliance with applicable standards and regulation.

Package Contents

Package Content	T62 Twin
Radio	2
Belt clip	2
Battery	2
Power Supply	1
Stickersheet	16
Owner's manual	1
Safety Manual	1
Warranty Card	1

Personalization Stickers:

Stickers are provided in order to personalize and keep track of radios. Use permanent marker for the blank stickers.

Frequency Chart



Channel	Frequency (MHz)	Channel	Frequency (MHz)	Channel	Frequency (MHz)
1	409.75000	8	409.83750	15	409.92500
2	409.76250	9	409.85000	16	409.93750
3	409.77500	10	409.86250	17	409.95000
4	409.78750	11	409.87500	18	409.96250
5	409.80000	12	409.88750	19	409.97500
6	409.81250	13	409.90000	20	409.98750
7	409.82500	14	409.91250		

Features and Specifications

- 20 Analog Channels
- 121 Sub-Codes (38 CTCSS Codes & 83 DCS codes)
- iVOX/VOX
- 20 Selectable Call Tone Alerts
- Backlit LCD Display
- Roger Tone
- Micro USB Connector for charging
- Battery Level Meter
- Channel Monitor
- Channel Scan
- Dual Channel Monitor
- Keypad Lock
- Auto Squelch Control
- Auto Repeat (Scrolling)
- Battery Low Alert
- Keypad Tone (On/Off)
- Power Source: NiMH battery Pack/3 x AA Alkaline batteries
- Battery Life: Up to 16 Hours (Typical battery life, 5/5/90 profile. Actual observed runtimes may vary)

Note: Range may vary depending on environmental and/or topographical conditions.

Radio Control Buttons and Display



Installing the Batteries

Each radio can either use a NiMH rechargeable battery pack or three units of AA Alkaline Battery, and beeps when the batteries are low.

1. Make sure your radio is turned off.
2. To remove the battery compartment door, press the tab at the bottom of the compartment door.
3. For NiMH battery pack, insert the battery pack with the ⊕ and ⊖ signs facing you. Observe polarity.
For AA Alkaline batteries, insert the batteries. Observe polarity.
4. Close the battery compartment door.

Low Battery Alert: When the battery is low, the radio produces an audio alert periodically and after each PTT transmission.

Battery Capacity Maintenance

1. Charge the NiMH batteries once every three months when not in use.
2. For storage purposes, remove the battery from the radio.
3. Store the NiMH batteries in a temperature between -20 °C to 35 °C and in low humidity. Avoid damp conditions and corrosive materials.

Using the Micro-USB Charger

The micro-USB charger allows you to charge your NiMH battery pack.

1. Power off your radio before start charging.
2. Plug the micro-USB cable into the micro-USB charging port on your radio.

3. Connect the USB charger to a nearby and easily accessible wall power outlet.
4. An empty battery will be fully charged in 8 hours.
5. The battery meter bar will scroll when the battery is charging.

Note: When moving between hot and cold temperatures, do not charge the NiMH battery pack until the temperature acclimates (usually about 20 minutes).
For optimal battery life, remove the radio from the charger within 16 hours. Do not store the radio while connected to the charger.

Turning your Radio On and Off

Press and hold the Power button to turn the radio on or off.

1. In the on position, the radio chirps and briefly shows all feature icons available on the radio.
2. The display screen then shows the current channel, code, and all features that are enabled.

Setting the Volume

From Standby Mode, press on either ⊕ or ⊖ to show the current value. Press ⊕ or ⊖ again to adjust the volume setting.

1. Press ⊕ to increase the speaker volume.
2. Press ⊖ to decrease the speaker volume.

Do not hold the radio close to your ear. If the volume is set to an uncomfortable level, it could hurt your ear. Adjust '0' to mute the speaker.

Talking and Listening

All radios in your group must be set to the same channel and Sub-Code in order to communicate.


1. Hold your radio 2–3 cm from your mouth.
2. Press and hold the **PTT** button while speaking. The Transmit **Tx** icon appears on the display.
3. Release the **PTT** button. You can now receive incoming calls. When you do, the Receive **Rx** icon appears on the display.

For maximum clarity, hold the radio 2 to 3 cm away and avoid covering the microphone while talking.

Talk Range

Your radio is designed to maximize performance and improve transmission range. Ensure the radios are at least 5 feet apart when in used.


Monitor Button

Pressing and holding  Scan/Monitor for 3 seconds to enter Monitor mode and listen for weak signals on the current channel. You can also listen to the volume level of the radio when you are not receiving. This allows you to adjust the volume, if necessary.

Push-to-Talk Time-out Timer





To prevent accidental transmissions and save battery life, the radio emits a continuous warning tone and stops transmitting if you press the **PTT** button for 60 seconds continuously.

Menu Options






Selecting the Channel

The channel is the frequency of the radio uses to transmit.

1. Press  Menu/Lock until the channel number starts to flash.
2. Press  or  to change the channel. Long press on these keys allows you to scroll through the channels rapidly to browse the codes.
3. Press **PTT** button to exit menu or  Menu/Lock to continue set up.





Note: Your radio has eight channels by default. In countries where 16 channels are allowed, you can activate Channels 9 to 16 with the following steps:

1. Press  Menu/Lock until the channel number starts to flash.
2. Press and hold down  and  simultaneously for 3 seconds until you hear a beep and "16 CH" is displayed briefly.

Selecting the Sub-Code

Sub-Codes help minimize interference by blocking transmissions from unknown sources. Your radio has 121 Sub-Codes.






To set the code for a channel:


1. Press  Menu/Lock until the code starts to flash.
2. Press  or  to select the code. You can hold down the button to speed up scrolling through the codes.
3. Press the **PTT** button to exit menu or  Menu/Lock to continue set up.

Setting and Transmitting Call Tones

Your radio can transmit different call tones to other radios in your group so you can alert them that you want to talk. Your radio has 20 call tones for you to choose from.


To set a call tone:

1. Press  Menu/Lock until the Call Tone  icon appears. The current call tone setting will flash.
2. Press  or  to change and listen to the call tone.
3. Press the **PTT** button to exit menu or  Menu/Lock to continue set up.



In order to transmit your call tone to other radios, set up the same channel and Sub-Code on your radio and press  Call Tone.

Easy Pairing

The Easy Pairing feature allows a group of radio users to program all their radios to the same Channel and Sub-Code settings quickly and simultaneously. Any one radio within the group can be designated as the "Leader's radio" and have it's Channel and Sub-Code settings transmitted to and copied by all the other radios in the group (Members' radios).

1. Pick any one of the radios as the "Leader's radio". On this radio, program the Channel and Sub-Code to the desired settings. (See "Selecting the Channel" and "Selecting the Sub-Code" sections in this user manual)
2. To copy the channel and Sub-Code combination to all the other "Members' radios", press and hold the  button on the Members' radios until you hear a beep. Release the button after the beep, and wait for the transmission from the Leader's radio.

Note:

- You will see the  icon blinking on the display. This confirms that the radio is in Easy Pairing mode waiting to receive the Channel and Sub-Code settings from the Leader's radio. All Members' radios will remain in this mode for 3 minutes.
 - A group with many radios should have all users take this step at the same time, so all radios can be programmed in one go.
3. On the Leader's radio, press and hold down the  button until you hear a double beep.


Note:




- At the double beep, this radio's Channel and Sub-Code settings will be transmitted, which will be received and copied by all the other (Members') radios.
- The Leader's radio must make this transmission when all the Members' radios are still in the Easy Pairing mode, otherwise the transmission will not be picked up.
- On the Leader's radio, user must remember not to release the button on the first (single) beep, otherwise this radio will become another Member's radio. If that happens, you can press **PTT** to escape, and retry the steps described in #3 again.

Internal Voice Operated Transmission/ Voice Operated Transmission (iVOX/VOX)

Transmission is initiated by speaking into the microphone of the radio/audio accessory instead of pushing the **PTT** button.

L3 = High Sensitivity for quiet environments
L2 = Medium Sensitivity for most environments
L1 = Low Sensitivity for noisy environments

- Press  Menu/Lock until the **iVOX** icon appears on the display. When audio accessory is connected, the **VOX** icon will be shown. The current setting (Off, L1–L3) will flash.








- Press  or  to select the sensitivity level.
- Press the **PTT** button to exit menu or  Menu/Lock to continue set up.

Note: When using iVOX/VOX, there will be a short delay.

Dual Channel Monitor

Enables you to scan the current channel and another channel alternately.






To set another channel and start Dual Channel Monitor:

- Press  Menu/Lock until the Dual Channel Monitor **2CH** icon appears. The Dual Channel Monitor icon will flash.
- Press  or  to select the channel then press  Menu.
- Press  or  to select the Sub-Code.
- Press the **PTT** button or wait until time out to activate Dual Channel Monitor. The screen will alternate between home channel and Dual Channel Monitor channel.
- To end Dual Channel Monitor, press  Menu/Lock.

Note: If you set the same channel and Sub-Code as the current channel, Dual Channel Monitor does not work.






Keypad Tones

You may enable or disable the keypad tones. You will hear the key tone each time a button is pushed.

1. Press  Menu/Lock until the Keypad Tone  icon appears. The current setting on/off will flash.
2. Press either  or  to turn on/off.
3. Press the **PTT** button to confirm or  Menu/Lock to continue set up.



Roger Tone



You can set your radio to transmit a unique tone when you finish transmitting. It is like saying "Roger" or "Over" to let others know you have finished talking.

1. Press  Menu/Lock until the Roger Tone  icon appears. The current setting on/off flashes.
2. Press  or  to turn on or off.
3. Press the **PTT** button to set or  Menu/Lock to continue set up.

Keypad Lock

To avoid accidentally changing your radio settings:

1. Press and hold  Menu/Lock until the Key Lock Indicator  icon displays.
2. You can turn the radio on and off, adjust the volume, receive, transmit, send a call tone, send Emergency Alert, and monitor channels when in the lock mode. All other functions remain locked.

3. Press  Menu/Lock and hold until the  Key Lock Indicator is no longer displayed to unlock the radio.

Scanning




Use the scan function to do the following:

- Search all channels for transmissions from unknown parties.
- Find someone in your group who has accidentally changed channels or
- To quickly find unused channels for your own use.




There is a priority feature and two modes of scanning (basic and advanced) to make your search more effective.

- The "Basic Scan" mode uses the channel and code combinations for each of the channel as you have set them (or with the default code value of 1).
- The "Advance Scan" mode will scan all channels for any and all codes; detect any code in use and use that code value temporary for that channel.
- Priority is given to the "Home Channel" (i.e. the channel and Sub-Code your radio is set to when you start the scan). This means the initial channel (and code settings) is scanned more often than the other seven channels and your radio will respond quickly to any activity occurring on the home channel as a priority.







To start Basic Scanning:

1. Press the  Scan/Monitor button briefly. The Scan  icon will appear in the display and the radio will begin to scroll through the channel and code combinations.
2. When the radio detects channel activities matching the channel and Sub-Code combination, the radio will stop scrolling and you can hear the transmission.
3. Press the **PTT** button within 5 seconds after the end of the transmission to respond and talk to the person transmitting.
4. The radio will resume scrolling through the channels 5 seconds after the end of any received activity.
5. Press the  Scan/Monitor button briefly to stop scanning.

To start Advanced Scanning:

1. Set home channel's Sub-Code to "zero" or off.
2. Press the  Scan/Monitor button briefly. The Scan  icon will appear in the display and the radio will begin to scroll through the channels. No Sub-Codes will filter what is heard.
3. When the radio detects channel activities with any code (or no code), it stops scrolling and you can hear the transmission. Any Sub-Code that may be use by other party will be detected and displayed.
4. To respond and talk to the person transmitting, press the **PTT** button within 5 seconds after the end of the transmission.
5. The radio will resume scrolling through the channels 5 seconds after the end of any received activity.
6. Press the  Scan/Monitor button briefly to stop scanning.

Note:

1. The transmission will be on the "Home Channel" if you press the **PTT** button while the radio is scrolling through inactive channels. You may press the  Scan/Monitor button to stop scanning at any time.
2. You may immediately resume the scan by briefly pressing  or  if the radio stops on an undesired transmission.
3. You may temporarily remove that channel from the scan list by pressing and holding  or  for 3 seconds if the radio stops repeatedly on an undesired transmission. You may remove more than one channel this way.
4. Turn the radio off and then turn back on, or exit and re-enter the scanning mode by pressing  Scan/Monitor to restore and remove channel(s) to the scan list.
5. You cannot remove the "Home Channel" from the scan list.
6. In the Advanced Scan, the detected code will only be used for one transmission. You must take note of that code, exit scan, and set the detected code on that channel to permanently use.

Warranty Information

The authorized Motorola Solutions dealer or retailer where you purchased your Motorola Solutions two-way radio and/or original accessories will honour a warranty claim and/or provide warranty service.

Please return your radio to your dealer or retailer to claim your warranty service. Do not return your radio to Motorola Solutions.

In order to be eligible to receive warranty service, you must present your receipt of purchase or a comparable substitute proof of purchase bearing the date of purchase. The two-way radio should also clearly display the serial number. The warranty will not apply if the type or serial numbers on the product have been altered, deleted, removed, or made illegible.

What Is Not Covered By The Warranty

- Defects or damage resulting from use of the Product in other than its normal and customary manner or by not following the instructions in this user manual.
- Defects or damage from misuse, accident or neglect.
- Defects of damage from improper testing, operation, maintenance, adjustment, or any alteration or modification of any kind.
- Breakage or damage to aerials unless caused directly by defects in material or workmanship.
- Products disassembled or repaired in such a manner as to adversely affect performance or prevent adequate inspection and testing to verify any warranty claim.
- Defects or damage due to range.
- Defects or damage due to moisture, liquid or spills.
- All plastic surfaces and all other externally exposed parts that are scratched or damaged due to normal use.
- Products rented on a temporary basis.
- Periodic maintenance and repair or replacement of parts due to normal usage, wear and tear.

Copyright Information

The Motorola Solutions products described in this manual may include copyrighted Motorola Solutions programs, stored semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola Solutions, certain exclusive rights for copyrighted computer programs, including the exclusive right to copy or reproduce in any form, the copyrighted Motorola Solutions programs.

Accordingly, any copyrighted Motorola Solutions computer programs contained in the Motorola Solutions products described in this manual may not be copied or reproduced in any manner without express written permission of Motorola Solutions. Furthermore, the purchase of Motorola Solutions products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Motorola Solutions, except for the normal non-exclusive royalty free license to use that arises by operation of law in the sale of a products.

Part Name	Hazardous Substances					
	(Pb)	(Hg)	(Cd)	(Cr + 6)	(PBB)	(PBDE)
Housing	O	O	O	O	O	O
Display PCBA	O	O	O	O	O	O
PCBA	X	O	O	O	O	O
Cable	O	O	O	O	O	O
Battery	X	O	O	O	O	O
PSU	X	O	O	O	O	O
Charger Tray	X	O	O	O	O	O
This table is prepared according to SJ/T 11364.						
O: Indicates that the content of such hazardous substance in all homogeneous materials of such component is within the limits specified in GB/T 26572.						
X: Indicates that the content of such hazardous substance in at least one homogeneous material of such component exceeds the limits specified in GB/T 26572.						

Notes

便携式双向对讲机的射频能量辐射和产品安全指南

注意!

使用本产品前，请阅读对讲机附带的《射频能量辐射和产品安全指南》，其中包含有关安全使用以及射频能量认识和控制的说明，以便遵守适用的标准和法规。

包装内容

包装内容	T62 双
对讲机	2
皮带夹	2
电池	2
电源	1
贴纸集	16
使用手册	1
安全手册	1
保修卡	1

个性化贴纸:

提供贴纸集，可用于个性化和跟踪对讲机。使用颜色擦不掉的麦克笔来写空白贴纸。

频率图表



信道	频率(MHz)	信道	频率(MHz)	信道	频率(MHz)
1	409.75000	8	409.83750	15	409.92500
2	409.76250	9	409.85000	16	409.93750
3	409.77500	10	409.86250	17	409.95000
4	409.78750	11	409.87500	18	409.96250
5	409.80000	12	409.88750	19	409.97500
6	409.81250	13	409.90000	20	409.98750
7	409.82500	14	409.91250		

功能和规格

- 20 个模拟信道
- 121 个子代码 (38 个 CTCSS 代码和 83 个 DCS 代码)
- iVOX/VOX
- 20 个可选的呼叫提示音提示
- 背光 LCD 显示屏
- Roger 提示音
- 微型 USB 充电连接器
- 电池电量表
- 信道监听
- 信道扫描
- 双信道监听
- 键盘锁定
- 自动降噪控制
- 自动重复 (滚动)
- 电池电量低提示
- 键盘音 (开/关)
- 电源: 镍氢电池组/3 节 AA 碱性电池
- 电池寿命: 长达16小时 (5/5/90工作周期。实际观察到的 电池运行时间可能存在差异)

注意: 覆盖范围会因环境或地形条件而异。

对讲机控制按键和显示屏



安装电池

每个对讲机都可以使用镍氢可充电电池组或三节 AA 碱性电池，并且会在电池电量低时发出蜂鸣声。

1. 确保对讲机已关闭。
2. 要取下电池盒盖，请按电池盒盖底部的卡舌。
3. 对于镍氢电池组，插入电池组，插入时 ⊕ 和 ⊖ 符号朝向您。注意极性。
对于 AA 碱性电池，插入电池。注意极性。
4. 合上电池盒盖。

低电量警告：当对讲机电量低时，对讲机会间歇发出警告音，并在每次释放 PTT 按键后发出警告音。

电池容量维护

1. 不使用时，每三个月为镍氢电池充电一次。
2. 存放时，从对讲机上取下电池。
3. 将镍氢电池存放在温度介于 -20 °C 至 35 °C 之间且湿度低的地方。避免潮湿情况和腐蚀性材料。

使用微型 USB 充电器

微型 USB 充电器让您可给镍氢电池组充电。

1. 在开始充电前关闭对讲机电源。
2. 将微型 USB 电缆插入对讲机上的微型 USB 充电端口。
3. 将 USB 充电器连接到附近方便插拔的电源插座。
4. 为电量耗尽的电池充满电需要 8 小时。

5. 电池正在充电时，电池电量计量仪格将滚动。

注意：在热冷温度之间移动时，请等待到镍氢电池组适应温度变化之后，才为它充电（一般需要 20 分钟左右）。

要获得最佳电池寿命，请在 16 小时内从充电器中拔下对讲机。存放对讲机时，请勿连接到充电器。

打开和关闭对讲机

按住电源按钮以打开或关闭对讲机。

1. 在打开位置，对讲机会发出啾啾音并简短显示对讲机上可用的所有功能图标。
2. 显示屏接着显示当前信道、代码和启用的所有功能。

设置音量

在待机模式下，按下 ⊕ 或 ⊖ 以显示当前值。再次按下 ⊕ 或 ⊖ 以调整音量设置。

1. 按下 ⊕ 以调高扬声器音量。
2. 按下 ⊖ 以调低扬声器音量。

切勿让对讲机靠近您的耳朵。如果音量设置不合宜，可能会损伤您的听力。调整到“0”会将扬声器静音。

通话和收听

您的组中的所有对讲机都必须设置为相同的信道和子代码，才能进行通信。


1. 将对讲机拿到离嘴巴 2-3 厘米处。
2. 讲话时按住 **PTT** 按钮。显示屏上将显示发射 **Tx** 图标。
3. 松开 **PTT** 按钮。现在，您可以接收呼入呼叫。执行此操作时，显示屏上将显示接收 **Rx** 图标。

要获得最大清晰度，请将对讲机拿到离嘴部 2-3 厘米处，并且避免在通话时盖住麦克风。

通话范围

您的对讲机在设计上可最大程度提升性能并扩大传输范围。使用时确保对讲机至少距离 5 英尺。


监听键

按住  扫描/监听 3 秒，以进入监听模式并侦听当前信道上的弱信号。当您未在收听时，还可以侦听对讲机的音量级别。这让您可根据需要调整音量。

通话按键超时计时器





为了防止意外传输和延长电池寿命，如果您持续按下 PTT 按键 60 秒，对讲机将发出连续警告提示音并停止传输。

菜单选项






选择信道

信道是指对讲机用于传输的频率。

1. 按下  菜单/锁定，直至信道编号开始闪烁。
2. 按下  或  以更改信道。长按这些按键将让您可快速滚动浏览信道，以浏览代码。
3. 按下 **PTT** 按钮以退出菜单，或按下  菜单/锁定以继续设置。





注意：默认情况下，您的对讲机有八个信道。在允许 16 个信道的国家/地区，您可以使用以下步骤激活信道 9-16：

1. 按下  菜单/锁定，直至信道编号开始闪烁。
2. 同时按住  和  3 秒，直至您听到一声蜂鸣声且看到短暂显示的“16 CH”。

选择子代码

子代码可通过阻止未知来源的传输，将干扰降至最低。您的对讲机具有 121 个子代码。






要设置信道的代码，请执行以下操作：


1. 按下  菜单/锁定，直至代码开始闪烁。
2. 按下  或  以选择代码。您可以按住该按键以加速滚动浏览代码。
3. 按下 **PTT** 按钮以退出菜单，或按下  菜单/锁定以继续设置。

设置和发射呼叫提示音

您的对讲机可以将不同的呼叫提示音发射到您组中的其他对讲机，以便您可以提示他们您想要通话。您的对讲机有 20 种呼叫提示音可供您选择。


要设置呼叫提示音，请执行以下操作：

1. 按下  菜单/锁定，直至呼叫提示音  图标显示出来。当前呼叫提示音设置将闪烁。
2. 按下  或  以更改并聆听呼叫提示音。
3. 按下 **PTT** 按钮以退出菜单，或按下  菜单/锁定以继续设置。



为了将您的呼叫提示音发射到其他对讲机，请在您的对讲机上设置相同的信道和子代码，然后按下  呼叫提示音。

轻松配对

轻松配对功能让一组对讲机用户可快速、同时将其所有对讲机都编程为相同的信道和子代码设置。该组中的任何一台对讲机都可被指定为“领导者对讲机”，并将其信道和子代码设置发射到该组中的其他所有对讲机（成员对讲机）并复制。

1. 挑选任意一台对讲机作为“领导者对讲机”。在此对讲机上，将信道和子代码设置为所需设置。（请参阅本用户手册中的“选择信道”部分和“选择子代码”部分。）
2. 要将信道和子代码组合复制到其他所有“成员对讲机”，请按住成员对讲机上的  按钮，直到听到一声蜂鸣声。听到蜂鸣声后松开该按钮，并等待领导者对讲机传输设置。

注意：

- 您将看到  图标在显示屏上闪烁。这确认对讲机处于轻松配对模式，正在等待接收来自领导者对讲机的信道和子代码设置。所有成员的对讲机都将保持在此模式 3 分钟。
 - 包含许多对讲机的组应让所有用户同时执行此步骤，以便所有对讲机同时编程。
3. 在领导者对讲机上，按住  按钮，直至您听到一声双音蜂鸣声。





注意：

- 在听到双音蜂鸣声时，将发射此对讲机的信道和子代码设置，而其他所有（成员）对讲机都将接收并复制这些设置。
- 领导者对讲机必须在所有成员对讲机仍处于轻松配对模式时进行此类传输，否则传输的设置无法被拾取。
- 在领导者对讲机上，用户必须记住不要在听到第一声（单音）蜂鸣声时松开按钮，否则此对讲机将变成另一台成员对讲机。如果发生这种情况，您可以按下 **PTT** 以退出，然后再次重试 #3 中介绍的步骤。

内部声控传输/声控传输 (iVOX/VOX)

发射通过对讲机/音频附件的麦克风说话发起，而不是通过按下 **PTT** 按钮发起。

L3 = 高灵敏度 ，适用于安静环境
L2 = 中灵敏度 ，适用于大多数环境
L1 = 低灵敏度 ，适用于嘈杂环境








1. 按下  菜单/锁定，直至 **iVOX** 图标出现在显示屏上。连接音频附件时，将显示 **VOX** 图标。当前设置（关，L1-L3）将会闪烁。
2. 按下  或  以选择灵敏度级别。
3. 按下 **PTT** 按钮以退出菜单，或按下  菜单/锁定以继续设置。

注意：使用 iVOX/VOX 时，将存在短暂延迟。

双信道监听

可让您交替扫描当前信道和另一个信道。






要设置另一个信道并启动双信道监听，请执行以下操作：

1. 按下  菜单/锁定，直至双信道监听 **2CH** 图标显示出来。双信道监听图标将闪烁。
2. 按下  或  以选择信道，然后按下  菜单。
3. 按下  或  以选择子代码。
4. 按下 **PTT** 按键或等待到超时，以激活双信道监听。屏幕将交替显示主信道和双信道监听信道。
5. 要结束双信道监听，请按下  菜单/锁定。

注意：如果您设置与当前信道相同的信道和子代码，双信道监听将无法运行。






键盘音

您可启用或禁用键盘音。每次按下某个按钮，都会听到按键音。

1. 按下  菜单/锁定，直至键盘音  图标显示出来。
当前设置“开/关”将闪烁。
2. 按下  或  以打开/关闭。
3. 按下 PTT 按钮以确认，或按下  菜单/锁定以继续设置。





Roger 提示音

可将对讲机设置为在完成发射后传输独特的提示音。这就像说“Roger”或“Over”，让其他人知道您已完成通话。

1. 按下  菜单/锁定，直至 Roger 提示音  图标显示出来。当前设置“开/关”将闪烁。
2. 按下  或  以打开或关闭。
3. 按下 PTT 按钮以设置，或按下  菜单/锁定以继续设置。

键盘锁定

要避免意外更改对讲机设置，请执行以下操作：

1. 按住  菜单/锁定，直至按键锁定指示器  图标显示出来。
2. 处于锁定模式时，您可以打开和关闭对讲机，调节音量，接收、发射、发送呼叫提示音，发送紧急提示，以及监听信道。其他所有功能都保持锁定状态。
3. 按住  菜单/锁定，直至不再显示  按键锁定指示器，以解锁对讲机。

扫描




使用扫描功能可执行以下操作：

- 搜索所有信道，了解是否有来自未知方的传输。
- 查找您组中意外更改信道的人员，或者
- 快速找到未使用的信道供您自己使用。



有一项优先级功能和两种扫描模式（基本和高级）让您的搜索更有效。


- “基本扫描”模式使用您为每个信道设置的信道和代码组合（或使用默认代码值 1）。
- “高级扫描”模式将扫描任何和所有代码的所有信道；检测任何使用中的代码并将该代码值临时用于该信道。
- “主信道”（即启动扫描时为您的对讲机设置的信道和子代码）将优先。这意味着，相比其他七个信道，将更频繁地扫描初始信道（和代码设置），而且对讲机将优先快速响应主信道上发生的任何活动。

要启动基本扫描，请执行以下操作：







1. 短按  扫描/监听按钮。扫描  图标将出现在显示屏上，而且对讲机将开始滚动浏览信道和代码组合。
2. 对讲机检测到与信道和子代码组合匹配的信道活动时，对讲机将停止滚动，并且您会听到传输的声音。
3. 在传输结束后的 5 秒内按下 PTT 按钮，以响应传输之人并与之通话。
4. 对讲机将在任何收到的活动结束后 5 秒恢复滚动浏览信道。
5. 短按  扫描/监听按钮以停止扫描。

要启动高级扫描，请执行以下操作：

1. 将主信道的子代码设置为“零”或“关”。
2. 短按  扫描/监听按钮。扫描  图标将出现在显示屏上，而且对讲机将开始滚动浏览信道。无子代码会过滤听到的内容。

3. 对讲机使用任何代码（或无代码）检测到信道活动时，将停止滚动，并且您会听到传输。将检测并显示其他方可使用的任何子代码。
4. 当您响应传输人员并与之通话时，在传输结束后 5 秒内按下 **PTT** 按钮。
5. 对讲机将在任何收到的活动结束后 5 秒恢复滚动浏览信道。
6. 短按  扫描/监听按钮以停止扫描。

注意：

1. 如果您在对讲机滚动浏览非活动信道时按下 **PTT** 按钮，将在“主信道”上传输。您可以随时按下  扫描/监听按钮以停止扫描。
2. 如果对讲机在意外传输时停止，通过短按  或 ，可立即恢复扫描。
3. 如果对讲机反复在意外传输时停止，通过按住  或  3 秒，可临时从扫描列表中删除该信道。您可以采用下面的方法删除多个信道。
4. 关闭再重新打开对讲机，或者退出然后重新进入扫描模式，方法是按下  扫描/监听，以将信道恢复到扫描列表和从扫描列表中删除信道。
5. 您不能从扫描列表中删除“主信道”。
6. 在高级扫描中，检测到的代码仅用于一次传输。您必须记下该代码，退出扫描，然后在该信道上设置检测到的代码以永久使用。

保修信息

您购买 Motorola Solutions 双向对讲机和/或原装附件的授权 Motorola Solutions 经销商或零售商将尊重保修要求和/或提供保修服务。

请将您的对讲机退还给经销商或零售商，以要求保修服务。不要将您的对讲机退还给 Motorola Solutions。

为了获得保修服务资格，您必须提供包含购买日期的购买收据或类似的替代购买证明。双向对讲机还应清晰显示序列号。如果产品上的类型或序列号已被修改、删除、移除或难以辨认，则保修将不适用。

保修不包括的范围

- 以错误方式使用产品或未遵循本用户手册中的说明造成的缺陷或损坏。
- 由于滥用、意外或疏忽造成的缺陷或损坏。
- 由于错误测试、操作、维护、调整或者任何类型的改造或修改造成的缺陷或损坏。
- 不是直接由于材料或工艺缺陷造成的天线破损或损坏。
- 会以给性能带来负面影响或阻止充分检查和测试来验证任何保修要求的方式拆卸或维修产品。
- 范围造成的缺陷或损坏。
- 潮湿、液体或溢出物造成的缺陷或损坏。
- 因正常使用而刮花或损坏的所有塑料表面和所有其他外露部件。
- 临时租赁的产品。
- 因正常使用和磨损产生的部件定期维护和维修或更换。

版权信息

本手册所介绍的 Motorola Solutions 产品可能包括受版权保护的 Motorola Solutions 程序、存储的半导体存储器或其他介质。美国和其他国家/地区的法律保护 Motorola Solutions 的某些受版权保护的电脑程序的专有权利，其中包括以任何形式拷贝或复制受版权保护的 Motorola Solutions 程序的专有权利。

因此，未经 Motorola Solutions 明确的书面许可，不得以任何方式对本手册中介绍的 Motorola Solutions 产品中包含的任何受版权保护的 Motorola Solutions 电脑程序进行拷贝或复制。除此之外，购买 Motorola Solutions 产品不应被认为拥有直接或暗示、禁止反言或其他方式的 Motorola Solutions 之版权、专利或专利申请的任何许可证授权，产品销售过程中法律运用所引起的普通非排他性免税许可证除外。

部件名称	有害物质					
	(Pb)	(Hg)	(Cd)	(Cr + 6)	(PBB)	(PBDE)
外壳	O	O	O	O	O	O
显示屏 PCBA	O	O	O	O	O	O
PCBA	X	O	O	O	O	O
电缆	O	O	O	O	O	O
电池	X	O	O	O	O	O
PSU	X	O	O	O	O	O
充电器托 盘	X	O	O	O	O	O
此表根据 SJ/T 11364 编制。						
O：表示此类组件的所有均质材料中的此类有害物质的含量在 GB/T 26572 规定的限制范围内。						
X：表示此类组件至少一种均质材料中的此类有害物质的含量超过 GB/T 26572 中规定的限制范围。						

备注

备注



MOTOROLA SOLUTIONS

无线电发射设备型号核准代码会在设备标签上注明。

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.

© 2021 Motorola Solutions, Inc. All rights reserved.



MN004538A02-AB

Printed in