

M500 Quick Start

Powering On

Your agency administrator typically configures the M500 to power on with your vehicle ignition.

- To power on the M500, start your vehicle.

The M500 boots up. When it has finished, the Display Screen shows the Live View streaming from the front camera.

Live View and Display Control Panel

Live View shows a live video stream overlaid with text and icons that give you information about the state of the system and let you access features with a touch. The Control Panel buttons allow you to control or access basic functions.




1	Current time and date	14	Access near real-time review player
2	Current GPS coordinates	15	Camera view changer
3	Active external inputs and crash indicator	16	Used storage for internal hard drive and USB drive
4	Wi-Fi signal strength, when Wi-Fi is available (MikroTik only)	17	Camera view indicator (text)
5	Event transfer status, connected or uploading	18	Patrol speed calculated using GPS
6	Active event recording indicator (red bars)	19	On: Power on the M500 and activate/deactivate Covert Mode
7	Camera view indicator (icon)	20	Off: Power off the M500
8	Livestream to CC Aware indicator	21	Home: Switch between menu and Live View
9	Associated body-worn cameras indicator	22	Record: Start a recorded event
10	Pending update icon	23	Stop: Stop a recorded event
11	Logged-in officer name	24	Cameras: Access views from system cameras
12	Vehicle ID	25	Display: Access display options
13	Microphone status, muted or unmuted		

Home

The **Home** menu gives you access to M500 functions and system information.

- From Live View, press **Home** on the Display Control Panel.




Review:	Opens the review by event feature
Status:	Shows current user, system, and network status information
Transfer:	Shows the status of event transfer to the evidence management system
Login/Logout:	Allows officers to associate their names with events recorded during their shifts
Record After the Fact:	Opens the Record-After-the-Fact® (RATF) feature to allow RATF event creation
Audio:	Allows officers to adjust the tone, review, and live audio volumes and wired microphone input levels
Settings:	Allows officers to adjust some system settings
Utilities:	Allows access to some system tools

Logging In

You log in to the M500 at the beginning of each shift to associate your name with the events recorded in your vehicle.

- From Live View, press **Home** on the Display Control Panel.
- Touch **Login** on the **Home** menu.

The login screen opens.



- Start entering your name, then touch your name when it appears on the list.

