



**Figure 1:** Pulling the Rubber Earloop

4. Push in the earloop to adjust to a comfortable position.
  5. Turn the radio on and adjust the audio volume to a comfortable listening level.
- Note:** When the earpiece is connected to the RSM and RSM speaker is muted, the audio is only heard from the earpiece speaker.
6. Turn the radio off before removing the earpiece from RSM.

**MOTOROLA SOLUTIONS**

# ADJUSTABLE D-STYLE EARPIECE with 3.5 mm Mono Jack for RSM **PMLN7396**

## USER GUIDE



**MN002333A01-AC**

Printed in



## **Foreword**

### **RF Energy Exposure and Product Safety Guide for Portable Two-Way Radios**

#### **Attention!**

This Adjustable D-Style Earpiece, when attached to the radio, is restricted to occupational use only to satisfy the Federal Communications Commission (FCC)/International Council on Non-Ionizing Radiation Protection (ICNIRP) RF energy exposure requirements. Before using this product, read the RF Energy Exposure and Product Safety Guide that ships with the radio which contains instructions for safe usage and RF energy awareness and control for compliance with applicable standards and regulation.

### **Acoustic Safety**

Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the volume, the less time is required before your hearing could be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect. To protect your hearing:

- Use the lowest volume necessary to do your job.
- Turn up the volume only if you are in noisy surroundings.
- Turn down the volume before connecting headset or earpiece.
- Limit the amount of time you use headsets or earpieces at high volume.
- When using the radio without a headset or earpiece, do not place the radio's speaker directly against your ear.

**Note:** For radio to detect the accessory properly, turn the radio off before connecting the audio accessory to the radio.

### **12 MONTHS LIMITED WARRANTY**

Manufacture warrants enclosed product against defects in material and workmanship under normal use and service for 12 months, provided it is returned in accordance with this warranty. If defective, the product will be repaired or replaced at manufacturer's option, at no charge, with dated proof of purchase. This warranty does not cover defects or damage resulting from: Misuse, improper operation, unauthorized modification, liquid, batteries, or normal wear and tear.

### **Description**

The PMLN7396 Adjustable D-Style Receive Earpiece allows you to receive messages in private when connected to the Remote Speaker Microphone (RSM). It can be worn over either side of the ears and provides comfortable and secure fit. The coiled cord is designed for flexibility in movement.

### **Operating Instruction**

1. Turn the radio off.
2. Attach the Adjustable D-Style Earpiece kit connector to the RSM.
3. Pull the rubber earloop to its largest size as shown in Figure 1, and slip it over the ear.