


Mag One Single-Unit Charger CZ089C601 Safety Leaflet



MN010551A01-AA

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.
© 2024 Motorola Solutions, Inc. All rights reserved.

Printed in



See *Mag One Single-Unit Charger CZ089C601 User Guide* (MN010561A01) for the complete online user guide and other languages at:
<https://learning.motorolasolutions.com>



en-US IMPORTANT SAFETY INSTRUCTIONS

This document contains important safety and operating instructions. Please read these instructions carefully and save them for future reference.

Before using the battery charger, read all the instructions and cautionary markings on (1) the charger, (2) the battery, and (3) the radio using the battery.



Caution

- To reduce risk of damage to the power cords, pull the plug rather than the cord when disconnecting from the AC outlet or the charger.
- An extension cord should not be used unless absolutely necessary. Use of an improper extension cord could result in risk of fire and electric shock. If an extension cord must be used, make sure that the cord size is 18 AWG for lengths of up to 6.5 feet (2.0 m), and 16 AWG for lengths up to 9.8 feet (3.0 m).
- To reduce risk of fire, electric shock, or injury, do not operate the charger if it has been broken or damaged in any way. Take it to a qualified Motorola Solutions service representative.

- Do not disassemble the charger. It is not repairable and replacement parts are not available. Disassembly of the charger may result in risk of electric shock or fire.
- To reduce risk of electric shock, unplug the charger power supply from the AC outlet before attempting any maintenance or cleaning.
- To reduce risk of injury, charge only the rechargeable Motorola Solutions Authorized Batteries listed in the *Mag One Single-Unit Charger CZ089C601 User Guide* (MN010561A01). Other batteries may explode, causing personal injury and damage.
- To reduce risk of fire, electric shock, or injury, do not use accessories not recommended by Motorola Solutions may result in risk of fire, electric shock, or injury.

OPERATIONAL SAFETY GUIDELINES

- This equipment is not suitable for outdoor use. Use only in dry locations and conditions.
- The room temperature must not exceed 40 °C (104 °F).
- The radio can be turned on only when it is transmitting data wirelessly, such as through Wi-Fi. Otherwise, turn off the radio.

- Connect the charger only to appropriate power supplies and power cords as listed in the *Mag One Single-Unit Charger CZ089C601 User Guide* (MN010561A01).
- The AC outlet to which the power supply is connected must be nearby and easily accessible.
- Ensure that the power supply cord connected to the charger is not easily stepped on, tripped over, or subjected to water, damage, or stress.
- Connect the power supply only to an appropriately fused and wired AC outlet with the correct voltage, as specified on the product.
- Disconnect from the line voltage by removing the power supply from the AC outlet.
- Connect not more than the appropriate number of charger power supplies to a 15 A or 20 A circuit, as limited by any certified power strip being used.
- The equipment shall be connected to a nearby and easily accessible socket outlet.

ADDITIONAL INFORMATION

The complete Online User Guide is available at <https://learning.motorolasolutions.com> through publication part number:

- Mag One Single-Unit Charger CZ089C601 User Guide* (MN010561A01)

zh-CN

重要安全说明

本文档包含重要的安全和操作说明。请仔细阅读这些说明，并妥善保管以供日后参考。
使用**电池充电器**之前，请阅读所有说明以及 (1) **充电器**、(2) **电池**和 (3) **使用电池的对讲机**上的警示标记。



注意

- 为了降低损坏电源线的风险，从交流插座或充电器中拔出电源线时，请捏住插头拔出，而不是拉电源线。
- 除非绝对必要，否则请勿使用电源延长线。使用不合适的延长线可能会引发火灾和导致触电。如果必须使用延长线，请确保延长线的规格为 18 AWG (最长不得超过 6.5 英尺 (2.0 米)) 或 16 AWG (最长不得超过 9.8 英尺 (3.0 米))。
- 为了降低火灾、触电或人员受伤的风险，请勿使用有任何破损或损坏的充电器。应将其交给符合资格的 Motorola Solutions 专业服务代表处理。

- 请勿拆开充电器。充电器不可维修且不提供更换部件。擅自拆开该充电器可能导致触电或引发火灾。
- 为了降低触电的风险，尝试对充电器进行维护或清洁之前，请先将充电器电源插头从交流插座上拔下。
- 为了降低人员受伤的风险，请使用 *Mag One 单座充电器 CZ089C601 用户指南* (MN010561A01) 中列出的经 Motorola Solutions 认可的可充电电池。其他类型的电池可能会发生爆炸，导致人员受伤和财产损失。
- 使用非 Motorola Solutions 推荐的附件可能会引发火灾、导致触电或人员受伤。

安全操作指南

- 本设备不适合在室外使用。请仅在干燥的场所和环境中使用。
- 室温不能超过 40 °C (104 °F)。
- 仅当无线传输数据 (例如使用 Wi-Fi 时) 时打开对讲机。否则，请关闭对讲机。
- 只能将充电器连接到 *Mag One 单座充电器 CZ089C601 用户指南* (MN010561A01) 中列出的适当电源和电源线上。
- 电源连接的交流插座务必要位于附近，并且插头方便。
- 确保充电器连接的电源线不会轻易发生踩踏、绊倒、浸水、损坏或挤压等意外。

- 电源只能与配有保险丝且电压匹配 (产品上指定的电压) 的有线交流电源插座连接。
- 通过从交流插座中拔出电源插头来断开线路电压。
- 受所使用的经认证电源板的限制，请将不超过适当数量的充电器电源连接到 15 A 或 20 A 电路。
- 设备应连接到位于附近且插头方便的插座。

其他信息

有关完整的联机用户指南，请访问 <https://learning.motorolasolutions.com> 并提供出版物部件号：

- Mag One 单座充电器 CZ089C601 用户指南* (MN010561A01)

주요 안전 지침

이 문서는 중요한 안전 및 작동 지침을 수록하고 있습니다. 지침을 주의 깊게

읽으신 후 향후 참고 자료로 활용할 수 있도록 보관하여 주십시오.

배터리 충전기를 사용하기 전에 (1) 충전기, (2) 배터리, (3) 배터리를 사용하는 무전기에 대한 지침과 주의 사항을 모두 숙지하십시오.



주의

1. 전원 코드에 대한 손상의 위험을 줄이기 위해 AC 콘센트 또는 충전기에서 분리할 때 코드 대신 플러그를 잡고 당기십시오.
2. 연장 코드는 꼭 필요하지 않은 이상 사용해서는 안 됩니다.

부적절한 연장 코드를 사용할 경우 화재나 감전의 위험이 있습니다. 연장 코드의 사용이 불가피하다면 최장 2.0m(6.5ft) 길이의 18AWG 규격 코드 및 최장 3.0m(9.8ft) 길이의 16AWG 코드를 사용하십시오.

3. 화재, 감전 또는 부상의 위험을 줄이기 위해, 충전기가 고장 났거나 손상된 경우 사용하지 마십시오. 공인 Motorola Solutions의 서비스 담당자에게 가져가십시오.
4. 충전기를 분해하지 마십시오. 충전기를 수리할 수 없으며, 교체 가능한 부품이 없습니다. 충전기를 분해하는 경우 감전 또는 화재의 위험이 있습니다.

5. 유지보수나 청소 시 감전될 수 있으므로 항상 사전에 AC 콘센트에서 충전기 전원 공급 장치를 분리하도록 하십시오.
6. 부상 위험을 줄이려면 *Mag One 싱글 유닛 충전기 CZ089C601 사용 설명서*(MN010561A01)에 나열된 Motorola Solutions 인증 충전식 배터리만 충전하십시오. 다른 배터리는 폭발의 위험이 있으며 폭발 시 부상 및 손상을 입을 수 있습니다.
7. Motorola Solutions에서 권장하지 않는 액세서리를 사용하는 경우, 화재, 감전 또는 부상의 위험이 있습니다.

작동 안전 지침

- 이 장비는 실외에서 사용하기에 적절하지 않습니다. 건조한 장소 및 환경에서만 사용하십시오.
- 실내 온도는 40°C(104°F)를 넘지 않아야 합니다.
- Wi-Fi 사용 등과 같이 데이터를 무선으로 송신 중일 때에만 무전기를 켜십시오. 그렇지 않은 경우 무전기를 끄십시오.
- 충전기를 *Mag One 싱글 유닛 충전기 CZ089C601 사용 설명서*(MN010561A01)에 나열된 적절한 전원공급장치 및 전원 코드에만 연결하십시오.
- 전원공급장치가 연결되어 있는 AC 콘센트는 가까운 곳에 있으며 접근성이 우수해야 합니다.
- 충전기에 연결된 전원공급장치 코드는 쉽게 밟히거나 걸려 넘어지거나 물기가 있거나 손상되거나 응력이 가해질 수 있는 곳을 피하여 설치해 주십시오.

- 제품이 명시된 대로 올바른 전압의 적절한 퓨즈가 장착된 유선 AC 콘센트에만 전원공급장치를 연결하십시오.
- AC 콘센트로부터 전원공급장치를 분리하여 선간 전압을 차단하십시오.
- 사용 중인 인증된 멀티탭의 제한에 따라 15A 또는 20A 회로에 적정수 이상으로 너무 많은 전원공급장치를 연결하지 마십시오.
- 가까이에 있으며 손쉽게 이용할 수 있는 소켓 콘센트에 장비를 연결해야 합니다.

추가 정보

전체 온라인 사용 설명서는

<https://learning.motorolasolutions.com>에 있는 부품 번호:

- *Mag One 싱글 유닛 충전기 CZ089C601 사용 설명서*(MN010561A01)를 참조하십시오.