



PROFESSIONAL DIGITAL TWO-WAY RADIO

MOTOTRBO™

**DP3441/DP3441e, DP3661e SERIES
PORTABLE RADIOS**

QUICK REFERENCE GUIDE

en-US



DECEMBER 2021

© 2021 Motorola Solutions, Inc. All rights reserved.



68012009021-BF

Your Quick Reference Guide

This Quick Reference Guide covers the basic operation of the radio. Check with your dealer or system administrator because your radio may have been customized for your specific needs.

For more operational details and information, refer to the following User Guide(s): https://www.motorolasolutions.com/en_xa/products.html

Important Safety Information

RF Energy Exposure and Product Safety Guide for Portable Two-Way Radios

Product Safety and RF Exposure Compliance



Caution: Before using this product, read the operating instructions for safe usage contained in the Product Safety and RF Exposure booklet enclosed with your radio.

ATTENTION!

This radio is restricted to Occupational use only. Before using the radio, read the RF Energy Exposure and Product Safety Guide for Portable Two-Way Radios which contains important operating instructions for safe usage and RF energy awareness and control for Compliance with applicable standards and Regulations.


Computer Software Copyrights

The Motorola Solutions products described in this manual may include copyrighted Motorola Solutions computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola Solutions certain exclusive rights for copyrighted computer programs including, but not limited to, the exclusive right to copy or reproduce in any form the copyrighted computer program.

Accordingly, any copyrighted Motorola Solutions computer programs contained in the Motorola Solutions products described in this manual may not be copied, reproduced, modified, reverse-engineered, or distributed in any manner without the express written permission of

Motorola Solutions. Furthermore, the purchase of Motorola Solutions products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Motorola Solutions, except for the normal non-exclusive license to use that arises by operation of law in the sale of a product.

Radio Control



1. Channel Selector Knob
2. On/Off/Volume Control Knob
3. LED Indicator
4. Push-to-Talk (PTT) Button
5. Programmable Side Button 1
6. Programmable Side Button 2
7. Programmable Front Button P1¹
8. Menu/OK Button¹
9. 4-Way Navigation Button¹
10. Return/Home Button¹
11. Programmable Front Button P2¹
12. Display¹
13. Microphone
14. Speaker
15. Universal Connector for Accessories
16. Programmable Emergency Button
17. Antenna

Attaching the Battery



Note:

For optimal performance, charge a new battery 14 to 16 hours before initial use.

1. Fit the battery into the slot at the bottom of the radio.
2. Push the top of the battery down until the latch snaps into place.

¹ Not for Non-Keypad models.

Attaching the Antenna

1. Turn off the radio.
2. Set the antenna in the receptacle and turn clockwise.

Turning the Radio On and Off

Rotate the **On/Off/Volume Control Knob** clockwise or counterclockwise until a click sounds.

Adjusting the Volume

Rotate the **On/Off/Volume Control Knob** clockwise or counterclockwise.

LED Indicators

Blinking Red

Radio has failed the self-test upon powering up, has moved out of range if Auto-Range Transponder System is configured, has Mute mode enabled, is receiving an emergency transmission, is transmitting in low battery state, or is indicating a battery mismatch².

Solid Green

Radio is powering up, transmitting, or sending a Call Alert or an emergency transmission.

Blinking Green

Radio is receiving a call or data, detecting activity over the air, or retrieving Over-the-Air Programming transmissions.

Double Blinking Green

Radio is receiving a privacy-enabled call or data.

Solid Yellow

Radio is monitoring a conventional channel or in Bluetooth Discoverable Mode.

Blinking Yellow

Radio is scanning for activity, has yet to respond to a Call Alert, or all Capacity Plus-Multi-Site channels are busy.

Double Blinking Yellow

Radio has Auto Roaming enabled, has yet to respond to a Group Call Alert, is actively searching for a new site, is not connected to the repeater while in Capacity Plus, is locked, or all Capacity Plus channels are busy.

Display Icons

The following icons appear on the status bar at the top of the radio display. The icons are arranged left most in order of appearance or usage, and are channel-specific.



Emergency



Scan³



High Volume Data



Mute Mode



Tones Disabled

² Only applicable to models with the latest software and hardware.

³ Not available for Capacity Max.



Ring Only



Vibrate and Ring



Notification



Response Inhibit



Secure



Unsecure



Site Roaming



Option Board



Power Level



Sign In



Sign Out

NOTES

www.motorolasolutions.com/motrbo

Printed in

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners. © 2021 Motorola Solutions, Inc. All rights reserved.

