

## DESCRIPTION

The RLN4941AXL Receive-Only Earpiece (Extra Loud Earphone) with Translucent Tube is a secondary receiver audio accessory that plugs into the 3.5 mm audio jack on compatible remote speaker or microphones (RSMs).

When attached, the earpiece provides a convenient means of receiving audio in the ear while muting audio from the remote speaker/microphone speaker.

The RLN4941AXL Receive-Only Earpiece (Extra Loud Earphone) with Translucent Tube includes a swivel clip that conveniently clips to a shirt collar or lapel to provide wearing comfort and prevent pulling the rubber eartip from the ear.

Four types of in-the-ear options are available:

- Standard Rubber Eartip (supplied with RLN4941AXL)
- Foam Earplug
- Clear Comfortable Earpiece, right ear
- Clear Comfortable Earpiece, left ear

Refer to the Replacement Parts section of this user guide for part numbers to order the in-the-ear options.

## OPERATION

### Attaching the Earpiece to the RSM

1. Remove the rubber seal from the 3.5 mm audio jack on the side of the RSM.
2. Insert the earpiece 3.5 mm plug into the microphone 3.5 mm audio jack.

### Wearing the Earpiece

To minimize interference and optimize earpiece performance, place the rubber eartip into the ear until the fit is snug. To provide a more secure fit (eartip to ear), loop the curved part of the translucent tube over the ear such that the coiled part of the tube hangs behind the ear. Then, attach the swivel clip to shirt collar or lapel.

### Receiving

When the earpiece is connected to the RSM and the RSM is connected to the radio, audio is heard only from the earpiece.

## Transmitting

Connecting the earpiece to the RSM and the RSM to the radio does not disable the radio microphone and push-to-talk (PTT) switch.

### Removing the Earpiece from the RSM

Carefully pull the earpiece 3.5 mm plug from the RSM 3.5 mm audio jack. Remember to reattach the RSM audio jack rubber seal when a secondary accessory is not being used.

## SERVICE

Other than replacing the rubber eartip (or other in-the-ear options), and the earphone itself, the RLN4941AXL Receive-Only Earpiece (Extra Loud Earphone) with Translucent Tube is not repairable.

Order replacement earpiece parts as necessary.

## Replacement Parts

Replacement parts supporting the RLN4941AXL are:

Description	Unit	Part Number
Standard Rubber Eartip	25/bag	5080370E97
Foam Earplug	50 pairs	5080384F72
Extra Loud Earphone (ships with RLN4941AXL)	1 each	5080369E46
Quick Disconnect Acoustic Tube Replacement	—	RLN6242
Clear Comfortable Earpieces, Right Ear:		
Small	1 each	RLN4760
Medium	1 each	RLN4761
Large	1 each	RLN4762
Clear Comfortable Earpieces, Left Ear:		
Small	1 each	RLN4763
Medium	1 each	RLN4764
Large	1 each	RLN4765

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners. © 2017 and 2021 Motorola Solutions, Inc. All rights reserved.



MN003963A01-AB

Printed in

## RECEIVE-ONLY EARPIECE (EXTRA LOUD EARPHONE) WITH TRANSLUCENT TUBE RLN4941AXL

### USER GUIDE



 **MOTOROLA SOLUTIONS**